

# SLHM75 Accessories

(included with machine)

NO.	ACCESSORIES	Qty	NO.	ACCESSORIES	Qty
1	2.5MM HEX WRENCH	1	14	MT3-32MM ARBOR	1
2	5MM HEX WRENCH	1	15	CHUCK KEY	1
3	6MM HEX WRENCH	1	16	SPANNER	1
4	8MM HEX WRENCH	1	17	INSTRUCTION MANUAL	1
5	10 MM HEX WRENCH	1			
6	SAFETY CHAIN	1			
7	THREE HANDLES	3			
8	COOLANT	1			
9	MT3-22B ARBOR	1			
10	20MM CHUCK	1			
11	MT2-MT1 ARBOR	1			
12	MT3-MT2 ARBOR	1			
13	MT3-19MM ARBOR	1			



## SLHM75 Spare Parts schematic

